

Fraunhofer Institute for Building Physics  
IBP

Research, development, demonstration  
and consulting in the field of building  
physics

Approval of new construction materials,  
components and methods

Officially recognized laboratory for test-  
ing, monitoring and certification

Director

Prof. Dr. Philip Leistner

Prof. Dr. Klaus Peter Sedlbauer

IBP-Report No. UHS-070/2020 EN

## **Studies to measure the efficiency of the ionair air quality ionization system against viruses**

Conducted on behalf of:

ionair AG  
Mr. Beda Weibel  
Staldenhof 3A  
6014 Luzern  
Switzerland

This report consists of:

14 pages text  
11 figures  
2 tables

Valley, December 14, 2020

Deputy Head:  
Dr.-rer. nat. Andrea Burdack-Freitag

Group Manager:  
M.Sc. Sabine Johann

## Table of content

<b>1</b>	<b>Test description</b>	<b>3</b>
<b>2</b>	<b>Method</b>	<b>4</b>
<b>3</b>	<b>Results</b>	<b>7</b>
<b>4</b>	<b>Conclusion</b>	<b>12</b>
<b>5</b>	<b>List of references</b>	<b>13</b>

# 1 Test description

The investigation aimed to test the reduction and inactivation of airborne surrogate viruses (enveloped Phi6 bacteriophage with a structure, particle size, and environmental stability comparable to SARS-CoV-2 [1], [2], [3], [4], [5]) by the ionization system for air purification (system specifications, according to the customer's specifications, see Table 1). The measurements carried out referred exclusively to the aerosolization of surrogate viruses in the air. The natural half-life of the viruses must be taken into account when calculating the efficiency of the ionization system.

The structure was based on DIN ISO 16000-36 [6] to investigate airborne bacteria, realistically adapted to the specific requirements of viruses. The viruses were analogous to the indoor air DIN-ISO 16000-16 [7] collected. The filters were processed based on DIN ISO 16000-17 [8]. The number of active viruses ("virulence") was determined in the laboratory using the plaque assay method ([9], [10]).

Table 1: System specification

Name of system	ICE-A2000 (power controller) with LQ1, LQ2, flow, humidity, and ozone sensor ionization module with four tubes (Development stage, see Fig. 1)
Manufacturer	ionair AG
Working principle	bipolar ionization and dielectrical barrier discharge; Module for installation in a flow channel (ID 25 cm)
IBP internal test number	E3378-2
Day of testing	October 21, 2020



Figure 1: ionair ionization module.

## 2 Method

The tests took place in a temperature, humidity, and volume flow-controlled test stand (flow channel setting parameters: 23 ° C, 50% r.H., 400 m<sup>3</sup> / h). The module was installed in the flow channel (see Figure 1). The preconditioned air flowing through was introduced into a connected test room (IBP-Indoor Air Test Center, IATC: 127 m<sup>3</sup>). The test setup is sketched in Figure 2.




Figure 2: Test set-up.

The investigations were continuously monitored using appropriate sensors, sampling, and dosing units:

- In the flow channel, approx. 5 m upstream in front of the ionizer: dosing unit for virus dosing (AGK2000 / Pallas),
- In the flow channel: Module 2 (ionair, TVOC and flow sensor upstream, ozone sensor downstream)
- In the IATC (IATC structure, see Figure 3): ozone measuring system (O3-41M / ansysco), particle measuring device (Fidas Frog / Pallas, 0.2 - 20 µm), particle measuring device (P-Trak, 20 - 1000 nm), TVOC sensor (ppbrae / Honeywell, 1 - 10,000 ppb), sampling unit for VOCs (BiVOC2 / Holbach) and viruses (MBASS30 / Holbach),
- In the exhaust airflow (according to IATC): Module 1 (ionair, TVOC, ozone, particle sensor).



Figure 3: Setup of the sensor technology and air sampler in the IATC room.

The virus aerosols (pre-pressure 1.5 bar) were introduced into the flow channel at a distance of 5 m in front of the ionizer. The dosing took place before the ionizer was switched on to achieve a constant viral load in the channel and IATC area. When constant dosing was reached, the first samples were taken (after 1 hour) to determine the maximum virus concentration and the associated VOC value. The ionizer unit was then switched on (2.24 h after the start of the metering) and allowed to run in for 2 h before the second sampling took place. After the end of the second sampling, the ionizer was switched off after a total running time of approx. 3 hours. The exact sampling times for airborne germ collections and dosing times are shown in Figure 4. The sampling duration for the various analyses: VOC, aldehyde/ketones and airborne microorganism sampler lasted approx. 1 hour each.

In accordance with the specifications of the German Federal Environment Agency, the determination of by-products generated during operation is required when using ozone-producing air purification processes (UV-C, plasma technology; ozone direct injection) [11]. This sampling was performed on corresponding adsorptive tubes for the detection of VVOCs and VOCs, analyzed by means of gas chromatography-mass spectrometry [12], as well as on DNPH cartridges for the determination of selected ketones and aldehydes, analyzed by means of high-performance liquid chromatography-diode array methods [13].




Figure 4: Diagram of the sampling and virus dosage referring to the time.

The effectiveness against viruses can be compared by the staircase-shaped test set-up consisting of the maximum viral load (sampling 1; P1) and the reduction effect of the ionair system (sampling 2; P2). During the entire running time, the particle distribution in the IATC from 20 nm to 20  $\mu$ m in the room, the temperature and humidity, and the TVOC, air ions, and ozone content were measured. The air germ samples taken were subjected to microbial analysis in a plaque assay test in the laboratory (see Figure 5).



Figure 5: Microbial analysis

### 3 Results

The air purification system pulled the virus-contaminated air through the filter channel. The action of the ionization module inactivated viruses inside the system, and the ozone formed.

The following Figure 6 to Figure 10 show the graph over the day of the experiment.

- Figure 6: Distribution of the virus particles in the IATC.
- Figure 7: TVOC concentrations at the measuring points in and at the IATC.
- Figure 8: Room climatic conditions on the test setup.
- Figure 9: Volume flows and flow velocities at the IATC.
- Figure 10: Ozone and carbon dioxide concentrations at the IATC.

The distribution of the virus particles (Figure 6) showed that the aerosolization of the Phi6 phages was constant over the dosing period. The two curves reflect the measuring ranges of the particle measuring systems (p-Trak / TSI and Fidas Frog / Pallas). The p-Trak covers the nanoscale range from 20 to 1000 nm and therefore mainly covers the range of individual viruses (virus size (approx. 100 nm) in the air). The Fidas Frog covers a more extensive scale from 0.2 to 20  $\mu\text{m}$  and thus detects aerosol-bound viruses (approx. 1 to 3  $\mu\text{m}$ ).

The TVOC values measured at the measuring points (Figure 7) show the interplay between the TVOC concentrations measured in the IATC and the control behavior of the ionair system, which readjusts moderately at different times. The indoor climate conditions in the IATC (Figure 8) and the set volume flows (Figure 9) each showed a constant measurement level between the sensor technology and the logged ionair measured values. The ozone concentration (Figure 10) in the IATC room rose to a maximum value of 45 ppb (equal to 90  $\mu\text{g}/\text{m}^3$ ).




Figure 6: Distribution of the virus particles in the IATC referring to the time.




Figure 7: TVOC concentrations at the measuring points in and at the IATC referring to the time.




Figure 8: Room climatic conditions on the test setup referring to the time.




Figure 9: Volume flows and flow velocity at the IATC referring to the time.




Figure 10: Ozone and carbon dioxide concentrations at the IATC referring to the time.

The laboratory analyses of substances formed by bipolar ionization and dielectrically hindered discharge (due to formed ozone) showed that few by-products could be detected. The by-products obtained were compared with the guideline value recommendations of the AIR [14]. The guideline value I (RW I) describes the concentration of a substance in indoor air at which, according to current knowledge, no adverse health effects are to be expected when considering individual substances, even if a person is exposed to this substance for a lifetime. This RW I was complied with for all by-products formed.

The number of viruses in the air was kept constant during the system's operating times (see Figure 6). The effectiveness of the ionizer is primarily based on inactivating the viruses. The virus activity measured in the laboratory is shown in Table 2.

Because the P1 was above the limit of quantification of  $> 10,000$  pfu/plate, the maximum concentration of  $3.3 \times 10^7$  [pfu/m<sup>3</sup>] was assumed for the calculation of the reduction. To calculate the reduction, the loss of activity in the suspension as a function of time (known from our own measurements and determined by the exponential function; see Figure 11 and Figure 12) was used.




Figure 11: Relative recovery of active or virulent phages in the phage suspension used for exponential metering equation (intersects y at 100%; a = 100)




Figure 12: Relative recovery of active or virulent phages in the phage suspension used for exponential metering equation (intersects y at 107.6%; a = 107))

Table 2: Measurement of virus activity taking into account the P3

Time of sampling	Active units (plaque-forming units) [pfu/m <sup>3</sup> ]	Measured reduction in viruses (pure Measurement data)	Calculated reduction rate R a=100 */**	Calculated reduction rate R a=107 */**
<b>P1 (before switching on the ionizer)</b>	3,3 x 10 <sup>7</sup> ***	-	-	-
<b>P2 (during ionizer operation)</b>	111.444 (± 7 %) (1,1 x 10 <sup>5</sup> )	0,9967 */****	0,9959 */****	0,9949 */****

\* Reduction rate  $R = 1 - C_t / C_i$  ( $C_i$  without commissioning the air cleaner and  $C_t$  with the air cleaner running).

\*\* taking into account the reduction in virus activity in suspension due to the exponential function with information on a

\*\*\* result above detection limit; Assumption: the agar plate was clear; this corresponds to a density of > 10,000 pfu/plate and therefore a concentration of  $3.3 \times 10^7$  pfu/m<sup>3</sup>

\*\*\*\* P1 was used as  $C_i$ .

## 4 Conclusion

The ionizer was built into the Fraunhofer IATC's air supply duct. Surrogate viruses (enveloped Phi6 bacteriophage with a structure, particle size, and environmental stability comparable to SARS-CoV-2) were continuously added, and their concentration was microbiologically analyzed before, during, and after switching on the ionizer. The supply air ionization system was able to reduce the virus concentration in the range of 99.49% \*/\*\*\*\* and 99.59% \*/\*\*\*\* after only 2.5 hours of system operation and a continuous virus load, while at the same time adhering to all health-relevant indoor air quality parameters.

It could be verified that no by-products (VOCs and aldehydes and ketones) exceeding RW I were formed by the air purification device.

During the measurement, a maximum ozone concentration of 90 µg/m<sup>3</sup> was measured in the air. The Federal Immission Control Act specifies up to 120 µg/m<sup>3</sup> as a safe upper limit (maximum target value). [15]. This target value was observed.

## 5 List of references

- [1] Carvallo, N.A. de, Stachler, E.N., Cimabue, N., Bibby, K. (2017): Evaluation of Phi6 Persistence and Suitability as an Enveloped Virus Surrogate. *Environmental Science & Technology* 51: 8692-8700.
- [2] Prussin, A.J., Schwake, D.O., Lin, K., Gallagher, D.L., Buttling, L., Marr, L.C. (2018): Survival of the Enveloped Virus Phi6 in Droplets as a Function of Relative Humidity, Absolute Humidity, and Temperature. *Applied and Environmental Microbiology* 84(12).
- [3] Whitworth, C., Mu, Y., Houston, H., Martinez-Smith, M., Noble-Wang, J., Coulliette-Salmond, A., Rose, L. (2020): Persistence of bacteriophage Phi 6 on Porous and Nonporous Surfaces and the Potential for Its use as an Ebola Virus or Coronavirus Surrogate. *Applied and Environmental Microbiology* 86(17): 1-11.
- [4] Casanova, L.M. & Waka, B. (2013): Survival of a Surrogate Virus on N95 Respirator Material. *Infection Control and Hospital Epidemiology* 34(12): 1334-1335.
- [5] Turgeon, N., Toulouse, M.-J., Martel, B., Molneau, S., Duchaine, C. (2014): Comparison of Five Bacteriophages as Models for Viral Aerosol Studies. *Applied and Environmental Microbiology* 80(14): 4242-4250.
- [6] DIN ISO 16000-36:2019-07, Innenraumluftverunreinigungen – Teil 36: Prüfkammer-Verfahren zur Bestimmung der Minderungsrate luftgetragener, kultivierbarer Bakterien durch Luftreiniger mit einer Prüfkammer.
- [7] DIN ISO 16000-16:2009-12, Innenraumluftverunreinigungen - Teil 16: Nachweis und Zählung von Schimmelpilzen - Probenahme durch Filtration.
- [8] DIN ISO 16000-17:2010-16 Innenraumluftverunreinigungen - Teil 17: Nachweis und Zählung von Schimmelpilzen – Kultivierungsverfahren.
- [9] Baer, A. & Kehn-Hall, K. (2014): Viral Concentration Determination Through Plaque Assaya: Using Traditional and Novel Overlay Systems. *Journal of Visualized Experiments* 93: 1-10.
- [10] Dulbecco, R. 1952. Production of plaques in monolayer tissue cultures by single particles of an animal virus. *Proc. Natl. Acad. Sci. USA* 38:747–752.
- [11] Umweltbundesamt, Stellungnahme der Kommission Innenraumluftthygiene (IRK), Einsatz mobiler Luftreiniger als Lüftungsunterstützende Maßnahme in Schulen während der SARS-CoV-2 Pandemie (Stand: 16. November 2020)

[12] DIN ISO 16000-3:2013-01 Innenraumluftverunreinigungen – Teil 3: Messen von Formaldehyd und anderen Carbonylverbindungen in der Innenraumluft und in Prüfkammern – Probenahme mit einer Pumpe.

[13] DIN ISO 16000-6:2012-11 Innenraumluftverunreinigungen – Teil 6: Bestimmung von VOC in der Innenraumluft und in Prüfkammern, Probenahme auf Tenax TA®, thermische Desorption und Gaschromatographie mit MS o-der MS-FID.

[14] Richtwertempfehlungen des AIR; Stand Oktober 2020

<https://www.umweltbundesamt.de/themen/gesundheit/kommissionen-arbeitsgruppen/ausschuss-fuer-innenraumrichtwerte-vormals-ad-hoc#hygienische-leitwerte-fur-die-innenraumluft>

[15] 39. BImSchV. Neununddreißigste Verordnung zur Durchführung des Bundes-Immissionsschutzgesetzes (Verordnung über Luftqualitätsstandards und Emissionshöchstmengen. Anlage 7 (zu §9) Zielwerte und langfristige Ziele für Ozon.